

Axial Piston Variable Double Pump A8VO

Series 61 and 63

RE 93010-01-B/05.09

Replaces: --
English

Operating Instructions



The data specified above only serve to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information. The information given does not release the user from the obligation of own judgment and verification. It must be remembered that our products are subject to a natural process of wear and aging.

© This document, as well as the data, specifications and other information set forth in it, are the exclusive property of Bosch Rexroth AG. It may not be reproduced or given to third parties without its consent.

An example configuration is shown on the title page. The delivered product may, therefore, differ from the product which is pictured.

The original operating instructions were created in the German language.

Contents

1	About this document	4
1.1	Related documents	4
1.2	Abbreviations used	5
2	General safety instructions	6
2.1	Intended use	6
2.2	Improper use.....	6
2.3	Personnel qualifications	6
2.4	Safety instructions in this document	7
2.5	Adhere to the following instructions	7
2.6	Operator's obligations	9
3	Delivery contents	10
4	Product description	11
4.1	Performance description	11
4.2	Device description.....	11
4.3	Product identification.....	16
5	Transport and storage	17
5.1	Transporting the axial piston unit.....	17
5.2	Storing the axial piston unit.....	19
6	Assembly	21
6.1	Unpacking	21
6.2	Installation conditions.....	21
6.3	Installation position	23
6.4	Assembling the axial piston unit.....	24
7	Commissioning	34
7.1	First commissioning	35
7.2	Recommissioning after standstill	37
7.3	Running-in phase.....	38
8	Operation	39
9	Maintenance and repair	40
9.1	Cleaning and care.....	40
9.2	Inspection.....	40
9.3	Maintenance	41
9.4	Repair	41
9.5	Spare parts	41
10	Decommissioning	42
11	Disassembly and replacement	42
11.1	Required tools.....	42
11.2	Preparing for disassembly	42
11.3	Disassembling the axial piston unit.....	42
11.4	Preparing the components for storage or further use	43
12	Disposal	44
12.1	Environmental protection	44
13	Extension and conversion	44
14	Troubleshooting	45
14.1	How to proceed for troubleshooting	45
14.2	Malfunction table.....	46
15	Technical data	48
16	Appendix	48
16.1	Address directory	48
17	Index	50

About this document

1 About this document

These instructions contain important information on the safe and appropriate assembly, transport, commissioning, maintenance, disassembly and simple troubleshooting of the axial piston variable double pump A8VO series 61 and 63.

- ▶ Read these instructions completely, especially chapter "2 General safety instructions", before working with the axial piston variable double pump A8VO.

1.1 Related documents

The axial piston variable double pump A8VO is a system component. Also observe the instructions for the other system components.

Further information on the axial piston variable double pump A8VO, its installation and operation can be found in the Rexroth documents listed in the following table.

Table 1: Related documents

Related documents	Contents
Order confirmation	Contains the preset technical data of your axial piston variable double pump A8VO.
Installation drawing	Contains the outer dimensions, all connections and the hydraulic circuit diagram for your axial piston variable double pump A8VO.
Data sheet RE 93010	Contains the permissible technical data for the axial piston variable double pump A8VO series 61 and 63.
Data sheet RE 90220	Describes the requirements on a mineral-oil based hydraulic fluid for operation with Rexroth axial piston units and assists you in selecting a hydraulic fluid for your system.
Data sheet RE 90221	Describes the requirements on an environmentally acceptable hydraulic fluid for operation with Rexroth axial piston units and assists you in selecting a hydraulic fluid for your system.
Data sheet RE 90223	Contains additional information on the use of Rexroth axial piston units with HF hydraulic fluids.
Data sheet RE 90300-03-B	Contains additional information on the use of Rexroth axial piston units at low temperatures.

Also observe the generally applicable, legal or otherwise binding regulations of the European and national legislation and the rules for the prevention of accidents and for environmental protection applicable in your country.

1.2 Abbreviations used

As umbrella term for "axial piston variable double pump A8VO", the designation "axial piston unit" will be used in the following.

Table 2: Abbreviations

Abbreviation	Meaning
A8VO	Axial piston variable double pump (parallel construction), for open circuits, size 55 (series 61) and sizes 80 through 200 (series 63)
DIN	Deutsche Industrie Norm (German Institute for Standardization)
EP	Proportional control, electric
ISO	International Organization for Standardization
LA0	Individual power control without override control
LA1	Individual power control, with override control by pilot pressure
RE	Rexroth document in the English language
VDI 2230	Directive for the systematic calculation of high duty bolted joints and joints with one cylindrical bolt from the VDI (Verein Deutscher Ingenieure - Association of German Engineers)

2 General safety instructions

The axial piston unit has been manufactured according to the generally accepted rules of current technology. There is, however, still a danger of personal injury or damage to equipment if the following general safety instructions and the warnings before the steps contained in these instructions are not complied with.

- ▶ Read these instructions completely and thoroughly before working with the axial piston unit.
- ▶ Keep these instructions in a location where they are accessible to all users at all times.
- ▶ Always include the operating instructions when you pass the axial piston unit on to third parties.

2.1 Intended use

Axial piston units are components in terms of the EU machine directive 98/37/EC (sub units). Axial piston units are not ready-to-use machines for the purpose of the EU machine directive. The product/component is exclusively intended for being integrated in a machine or system or for being assembled with other components to form a machine or system. The product may only be commissioned after it has been installed in the machine/system for which it is intended.

The axial piston variable double pump generates, controls and regulates a hydraulic fluid flow. It is approved for use as a hydraulic pump in hydrostatic drives in open circuits.

- ▶ Observe the technical data, operating conditions and performance limits as specified in the data sheet and order confirmation.

The axial piston unit is not designed for private use.

Intended use includes having read and understood these instructions, especially chapter "2 General safety instructions".

2.2 Improper use

The axial piston unit may not be used in explosive environments.

In addition, any use of the axial piston unit other than described in chapter "2.1 Intended use" is considered to be improper.

2.3 Personnel qualifications

Assembly, commissioning and operation, disassembly, maintenance and repair require basic mechanical, hydraulic and electrical knowledge, as well as knowledge of the appropriate technical terms. For transporting and handling the product, additional knowledge is necessary with regard to working with a lifting device and the corresponding attachment equipment. In order to ensure operating safety, these activities may therefore only be carried out by qualified personnel or an instructed person under the direction and supervision of qualified personnel.

Qualified personnel are those who can recognize possible hazards and institute the appropriate safety measures due to their professional training, knowledge, and experience, as well as their understanding of the relevant regulations pertaining to the work to be done. Qualified personnel must observe the rules relevant to the subject area.

2.4 Safety instructions in this document

In this manual, there are safety instructions before the steps whenever there is a danger of personal injury or damage to equipment. The measures described to avoid these hazards must be observed.

Safety instructions are set out as follows:

SIGNAL WORD!	Type of danger!
	Consequences ▶ Precautions

- **Safety sign** (warning triangle): draws attention to the danger
- **Signal word**: identifies the degree of the danger
- **Type of danger**: identifies the type or source of the danger
- **Consequences**: describes what could occur if the safety instructions are not complied with
- **Precautions**: states how the danger can be avoided.

The signal words have the following meaning:

Signal word!	Application
DANGER! 	Indicates an imminently hazardous situation which, if not avoided, will certainly result in death or serious injury.
WARNING! 	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
CAUTION! 	Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or damage to equipment.
	If this information is disregarded, the operating procedure may be impaired.

2.5 Adhere to the following instructions

General instructions

- Observe the regulations for accident prevention and environmental protection for the country where the product is used and at the workplace.
- Only use Rexroth axial piston units in good technical order and condition.
 - Inspect the product for obvious defects.
- Do not modify or retrofit the axial piston unit.
- Only use the product within the performance range provided in the technical data.

General safety instructions

- Persons who assemble, commission, operate, disassemble or maintain Rexroth products must not consume any alcohol, drugs or pharmaceuticals that may affect their ability to respond.
- The warranty only applies to the delivered configuration.
- The warranty is rendered void if the product is incorrectly assembled, commissioned or operated, as well as if not used as intended and/or handled improperly.
- Do not expose the product to any mechanical loads under any circumstances. Never use the product as a handle or step. Do not place/lay any objects on it.
- The noise emission of axial piston units depends on speed, operating pressure and installation conditions. The sound pressure level may rise above 70 dBA during normal operating conditions. This can cause hearing damage.
 - Always wear hearing protection while working in the vicinity of the operating axial piston unit.
- The axial piston unit heats up considerably during operation. The solenoids of the axial piston unit get so hot during operation that you may burn yourself:
 - Allow the axial piston unit to cool down sufficiently before touching it.
 - Wear heat-resistant protective clothing, e.g. gloves.
- Hydraulic fluid is easily flammable.
 - Keep open flames and ignition sources from the axial piston unit.

During transport

- Make certain that the lifting device has adequate lifting capacity. The weight can be found in chapter "5 Transport and storage".

During assembly

- Before assembling, make certain that all fluids have been removed from the axial piston unit to prevent mixing with the hydraulic fluid used in the system.
- Make certain that the relevant system component is not under pressure or voltage before assembling the product or when connecting and disconnecting plugs. Protect the system against being switched on.
- Lay cables and lines so that they cannot be damaged and no one can trip over them.
- Before commissioning, make certain that all hydraulic connections are tight and that all of the connection seals and plugs are installed correctly to ensure that they are leakproof and fluids and contaminants are prevented from penetrating the product.
- When assembling, provide for absolute cleanliness in order to prevent contaminants, such as welding beads or metal cuttings, from getting into the hydraulic lines and causing product wear or malfunctions.

During commissioning

- Ensure that all electrical and hydraulic connections and ports are occupied or plugged. Only commission a completely installed product.

During cleaning

- Plug all openings with the appropriate protective equipment in order to prevent detergents from penetrating the system.
- Never use solvents or aggressive detergents. Use only water and, if necessary, a mild detergent to clean the axial piston unit.
- Do not point high-pressure cleaners at sensitive components, e.g. shaft seal ring, electrical connections and electrical components.

During maintenance and repair

- Perform the prescribed maintenance work at the intervals specified in the operating instructions (see chapter "9.3 Maintenance").
- Make certain that no lines, connections or components are disconnected as long as the system is under pressure. Protect the system against being switched on.

Disposal

- Dispose of the product and the hydraulic fluid in accordance with the currently applicable national regulations in your country.

2.6 Operator's obligations

The operator of the axial piston unit from Rexroth must provide personnel training on a regular basis regarding the following subjects:

- Observation and use of the operating instructions and the legal regulations
- Intended use and operation of the axial piston unit
- Observation of the instructions from the factory security offices and of the work instructions from the operator



Rexroth offers training support for special fields. You can find an overview of the training contents on the Internet at:

<http://www.boschrexroth.de/didactic>.

3 Delivery contents




Fig. 1: Axial piston unit

Included in the delivery contents are:

- 1 Axial piston unit

The following parts are also assembled on delivery:

- Plastic transport protection for drive shaft (1)
- Plastic protective covers (2) (for painted axial piston units, metal protective covers are used)
- Plastic plugs / locking screws (3)
- For version with power take-off flange cover and fixing screws (4)

4 Product description

4.1 Performance description

The axial piston variable double pump generates, controls and regulates a hydraulic fluid flow. The A8VO is suitable for direct mounting on the flywheel case of a diesel engine.

Refer to the data sheet and order confirmation for the technical data, operating conditions and operating limits of the axial piston unit.

4.2 Device description

The A8VO is an axial piston variable double pump with two axial tapered piston rotary groups with bent-axis design for open-circuit hydrostatic drives. The axial piston variable double pump has a shared suction port for both circuits and the auxiliary pump. It generates two flows for supplying two separate circuits. Flow is proportional to drive speed and displacement. By adjusting the bent-axis rotary groups, the two flows can be steplessly changed independent of one another.

Open circuit With an open circuit, the hydraulic fluid flows from the tank to the variable pump and is transported from there to the consumer via a directional valve. From the consumer, the hydraulic fluid flows back to the tank via the directional valve.

4.2.1 Assembly of the axial piston unit




Fig. 2: Assembly of the A8VO

1 Drive shaft	4 Lens plate	7 Drive-shaft flange
2 Piston	5 Port plate	8 Service line port
3 Cylinder	6 Stroke piston	9 Suction port

Product description**4.2.2 Functional description**

- Pump** For axial piston units with bent-axis design, the pistons (2) are arranged at an angle to the drive shaft (1). When the drive shaft is turned, the cylinder (3) is picked up and set into motion cardan-free by the pistons, which are arranged in a ring on and flexibly connected to the drive-shaft flange (7). The cylinder then rotates over the spherical lens plate (4), in which two kidney-shaped control slots have been incorporated. As they turn, each of the pistons moves from top to bottom dead center and back, executing a stroke that depends on the swivel angle. The drive-shaft flange of both rotary groups, which lie parallel next to one another, are interlocked. The rotary group with the long drive shaft drives the second rotary group via the interlocked drive-shaft flange. On the low-pressure side, fluid flows into the enlarging piston chamber. At the same time, on the pressure side the fluid is pushed out of the cylinder chamber into the hydraulic system by the pistons. The pistons are braced against the drive-shaft flange by the load of the hydraulic pressure.
- Control** The swivel angle is changed hydraulically via the stroke piston (6). Here, the hydraulic part of the rotary group cylinder is swiveled, including the lens plate. As the angle is increased, the displacement and, thus, the necessary drive torque are increased. As it is reduced, the values are reduced accordingly. Displacement is zero when there is no angle of tilt.
- When depressurized, the pump is swiveled to its initial position $V_{g \max}$ by an adjustment spring.

Product description

The following variations of the individual power control without override control are available:

- **LA0H2** – with hydraulic stroke limiter, positive control and external pilot pressure supply
- **LA0S** – with load sensing
- **LA0K** – with hydraulic power coupling,
 - **LA0KS** – and load sensing
 - **LA0KH1** – and hydraulic stroke limiter, negative control
 - **LA0KH2** – hydraulic stroke limiter, positive control and external pilot pressure supply
 - **LA0KH3** – hydraulic stroke limiter, negative control and external pilot pressure supply

The following variations of the individual power control with override control through pilot pressure are available:

- **LA1H2** – with hydraulic stroke limiter, positive control and external pilot pressure supply
- **LA1S** – with load sensing
- **LA1K** – with hydraulic power coupling,
 - **LA1KS** – and load sensing
 - **LA1KH1** – and hydraulic stroke limiter, negative control
 - **LA1KH2** – hydraulic stroke limiter, positive control and external pilot pressure supply
 - **LA1KH3** – hydraulic stroke limiter, negative control and external pilot pressure supply

See data sheet for further information RE 93010.

EP - Electrical control with proportional solenoid

With the electrical control with proportional solenoid, the pump displacement is steplessly adjusted in proportion to the current by means of magnetic force.

Control from $V_{g\ min}$ to $V_{g\ max}$

With increasing control current, the pump swivels to a higher displacement.

Initial position without control signal (control current): $V_{g\ min}$

The required control fluid is taken either from the operating pressure or from the externally applied control pressure at the Y_3 port.

To ensure the control even at low operating pressure < 30 bar, port Y_3 must be supplied with an external control pressure of approx. 30 bar.



Load sensing "S" and electrical control EP:

When operated at $V_{g\ min}$ (> 5 min), the hydraulic fluid in the case can become heated to an impermissible temperature. Please contact us.

The following electronic controllers and amplifiers are available for controlling the proportional solenoids (details also available at www.boschrexroth.com/mobile-electronics):

- BODAS controller RC

Series 20	RE 95200
Series 21	RE 95201
Series 22	RE 95202
Series 30	RE 95203

 and application software
- Analog amplifier RA RE 95230




Fig. 4: Circuit diagram of A8VO with EP2, sizes 107 and 140

Product description

4.3 Product identification

The axial piston unit can be identified with the name plate. The following example shows an **A8VO** name plate:




Fig. 5: A4VSO name plate A8VO

- | | | | |
|---|--|----|--|
| 1 | Manufacturer | 8 | Barcode |
| 2 | Internal plant designation | 9 | Rotational speed |
| 3 | Sample category (optional) | 10 | Production date |
| 4 | Direction of rotation (looking at drive shaft) – here: clockwise | 11 | Serial number |
| 5 | Specified area for test stamp | 12 | Material number of the axial piston unit |
| 6 | Weight (optional) | 13 | Ordering code |
| 7 | Power | | |

5 Transport and storage

5.1 Transporting the axial piston unit

CAUTION!



Risk of damage!

Hitting or impulsive forces on the drive shaft can damage the axial piston unit.

- ▶ Do not hit the coupling or drive shaft of the axial piston unit.
- ▶ Do not set/place the axial piston unit on the drive shaft.
- ▶ Details on the permissible axial and radial forces can be found in the data sheet.

Axial piston units can be transported with a forklift truck or with a lifting device.

- ▶ Make certain that the forklift truck or lifting device has adequate lifting capacity.

Dimensions and weights

Table 3: Dimensions and weights A8VO

Size		55	80	107	140	200
Weight	kg	82	90	116	146	180
Width	mm	The dimensions vary with the unit type. Values valid for the axial piston unit can be found in the installation drawing (please request if needed).				
Height	mm					
Depth	mm					

The weight specifications may vary depending on the unit type. The precise weight can be found on the name plate.

5.1.1 Transporting with lifting device

For transporting, the axial piston unit can be connected to a lifting device via a ring screw or a lifting strap.

Transport with ring screw

The drive shaft can be used to transport the axial piston unit as long as only outward (pulling) axial forces occur. Thus, you can suspend the axial piston unit from the drive shaft.

- ▶ To do this, screw a ring screw completely into the thread on the drive shaft. The threaded sizes is stated in the installation drawing.
- ▶ Make certain that each ring screw can bear the total weight of the axial piston unit plus approx. 20 %.

You can hoist the axial piston unit as shown in Fig. 6 with the ring screw screwed into the drive shaft without any risk of damage.




Fig. 6: Fixing the ring screw

Transport and storage

- Transport with lifting strap**
- ▶ Place the lifting strap around the axial piston unit in such a way that it passes over neither the attachment parts (e.g. valves) nor such that the axial piston unit is hung from attachment parts (see Fig. 7).

WARNING!**Risk of injury!**

During transport with lifting device, the axial piston unit can fall out of the lifting strap and cause injuries.

- ▶ Hold the axial piston unit with your hands to prevent it from falling out of the lifting strap.
- ▶ Use the widest possible lifting strap.




Fig. 7: Transport with lifting strap

5.2 Storing the axial piston unit

Requirement

- The storage areas must be free from corrosive materials and gasses.
 - The storage areas must be dry.
 - The ideal temperature for storage lies between +5 °C and +20 °C.
 - The minimum storage temperature is -50 °C.
 - Avoid intense lights.
 - Do not stack axial piston units and store them shock-proof.
 - Do not store the axial piston unit on sensitive attachment parts, e.g. sensors.
 - For other storage conditions, see Table 4.
- Check the axial piston unit monthly to ensure proper storage.

After delivery

The axial piston unit is provided ex-works with a corrosion protection packaging (corrosion protection film).

Listed in the following table are the maximum permissible storage times for an originally packed axial piston unit.

Table 4: Storage time with factory corrosion protection

Storage conditions	Standard corrosion protection	Long-term corrosion protection
Closed, dry room, uniform temperature between +5 °C and +20 °C. Undamaged and closed corrosion protection film.	Maximum 12 months	Maximum 24 months



The warranty is rendered void if the requirements and storage conditions are not adhered to or after expiration of the maximum storage time (see Table 4).

Procedure after expiration of the maximum storage time:

1. Check the entire axial piston unit for damage and corrosion prior to installation.
2. Check the axial piston unit for proper function and leaks during a test run.
3. If the storage time exceeds 24 months, the shaft seal ring must be replaced.



After expiration of the maximum storage time, we recommend that you have the axial piston unit inspected by your responsible Rexroth Service partner.

In the event of questions regarding repair and spare parts, contact your responsible Rexroth Service partner or the service department of the manufacture's plant for the axial piston unit, see chapter "9.5 Spare parts" for further information.

After disassembly

If a dismantled axial piston unit is to be stored, it must be conserved against corrosion for the duration of the storage.



The following instructions only refer to axial piston units which are operated with a mineral-oil based hydraulic fluid. Other hydraulic fluids require conservation methods that are specifically designed for them. In such a case, consult with Rexroth Service (see chapter "9.5 Spare parts" for address).

Rexroth recommends the following procedure:

1. Clean the axial piston unit, see chapter "9.1 Cleaning and care" for further information.
2. Completely empty the axial piston unit.

Transport and storage

3. For storage time up to 12 months: Moisten the inside of the axial piston unit with mineral oil and fill with approx. 100 ml mineral oil.
For storage time up to 24 months: Fill the axial piston unit with corrosion protection VCI 329 (20 ml).
Fill via the highest port "**R**", see chapter "6.4 Assembling the axial piston unit", Figs. 12 through 14.
4. Seal all ports airproof.
5. Moisten the unpainted surfaces of the axial piston unit with mineral oil.
6. Package the axial piston unit airproof together with desiccant in corrosion protection film.
7. Store the axial piston unit so that it is protected against jolts. See "Requirement" in this chapter for further conditions.

6 Assembly

Prior to assembly, the following documents must be available:

- Installation drawing for the axial piston unit (available from Rexroth)
- Hydraulic circuit diagram for the axial piston unit (in the installation drawing)
- Hydraulic circuit diagram for the system (available from the system manufacturer)
- Order confirmation (contains the preset data of the axial piston unit)
- Data sheet for the axial piston unit (contains the technical data)

6.1 Unpacking

The axial piston unit is delivered in a corrosion protection film made of polyethylene material.

- ▶ Dispose of the packaging according to the national regulations of your country.

CAUTION!**Risk of parts falling out**

If the packaging is not opened correctly, parts may fall out and damage the parts or even result in injury.

- ▶ Place the packaging on a flat and solid surface.
 - ▶ Only open the packaging from the top.
-

6.2 Installation conditions

- The installation location and position of the axial piston unit essentially determine the procedures during installation and commissioning (such as when filling the axial piston unit).
- Note that you can expect certain installation positions to affect the control device. Because of gravity, dead weight and case pressure, minor characteristic displacements and actuating time changes may occur.
 - ▶ Adhere to all limits specified in the data sheet regarding temperature, viscosity, cleanliness of the hydraulic fluid.
 - ▶ Make certain that the case of the axial piston unit is filled with hydraulic fluid during commissioning and operation. This is also to be observed following relatively long standstill periods as the axial piston unit may empty via the hydraulic lines.
 - ▶ To achieve favorable noise values, decouple all connecting lines from all vibration-capable components (e.g. tank) using elastic elements.

Assembly

- ▶ Make certain that the suction line flows into the tank below the minimum fluid level in all operational states.




Fig. 8: Suction pressure

- 1 Absolute pressure gauge
- 2 Standard pressure gauge

- ▶ Make certain that a minimum suction pressure of 0.8 bar absolute is present at port "S" during operation in all installation positions and installation locations for the axial piston pump, see Fig. 8. See data sheet for additional values.
- ▶ Absolute cleanliness is required. The axial piston unit must be installed in a clean condition. Contamination of the hydraulic fluid can have a considerable impact on the service life of the axial piston unit.
- ▶ Do not use any cotton waste or linty cloths for cleaning.
- ▶ Use suitable liquid detergents to remove lubricants and other difficult-to-remove contamination. Detergents must not penetrate the hydraulic system.

CAUTION!

Risk of damage by air inclusions!

An air pocket in the area near the bearings will damage the axial piston unit.

- ▶ Make certain that the case is completely filled with hydraulic fluid during commissioning and operation.
 - ▶ During commissioning and during operation, the suction line must be filled with hydraulic fluid.
-

6.3 Installation position

The following installation positions are permissible. The shown piping layout illustrates the basic layout.



The case drain chamber is internally connected to the suction chamber. A separate case drain line from the case to the tank is not required.

6.3.1 Below-tank installation

Below-tank installation is when the axial piston unit is installed outside of the tank below the minimum hydraulic fluid level.




Fig. 9: Below-tank installation with installation positions 1–2

R₁, R₂	Air bleed port or fluid drain	h_{t min}	Minimum permissible immersion depth (200 mm)
R₃		h_{min}	Minimum permissible spacing from suction port to tank base (100 mm)
S	Suction port		

Table 5: Below-tank installation

Installation position	Air bleeding	Filling
1 (drive shaft, horizontal)	R ₃	S + R ₃
2 (drive shaft, horizontal)	R ₂	S + R ₂

6.4 Assembling the axial piston unit

DANGER!



Systems which are in operation pose a risk of injury!

Working on operating systems poses a danger to life and limb. The work steps described in this chapter must only be performed on systems which are at a standstill. Before beginning work:

- ▶ Ensure that the engine cannot be switched on.
- ▶ Ensure that all power-transmitting components and connections (electric, pneumatic, hydraulic) are switched off according to the manufacturer's instructions and are secured against being switched on again. If possible, remove the main fuse for the system.
- ▶ Ensure that the system is completely hydraulically relieved and depressurized. Please follow the system manufacturer's instructions.
- ▶ Only qualified personnel (see chapter "2.3 Personnel qualifications") are authorized to assemble the axial piston unit.

6.4.1 Preparation

1. Check the delivery contents for completeness and transport damages.
2. Compare the material number and designation (ordering code) with the details in the order confirmation.



If the material number for the axial piston unit does not correspond to the one in the order confirmation, contact Rexroth Service for clarification, see chapter "9.5 Spare parts" for address.

3. Before assembling, completely empty the axial piston unit to prevent mixing with the hydraulic fluid used in the system.
4. Check the direction of rotation of the axial piston unit (on the name plate) and make certain that this corresponds to the direction of rotation of the engine. The axial piston unit is only delivered with clockwise rotation.




Fig. 10: Direction of rotation

R Clockwise



The direction of rotation as specified on the name plate determines the direction of rotation of the axial piston unit as viewed on the drive shaft. For information on the direction of rotation of the engine, please refer to the engine manufacturer's operating instructions.

6.4.2 Dimensions

The installation drawing contains the dimensions for all ports on the axial piston unit. Also observe the instructions provided by the manufacturers of the other components when selecting the required tools.

6.4.3 General instructions

During assembly (and disassembly) of the axial piston unit, observe the following general instructions and handling instructions:

- When transferring the input or output drive of an axial piston unit with the aid of a cardan shaft, vibrations may occur which could result in leakages on the shaft seal ring of the axial piston unit depending on the frequency and temperature.
- ▶ Fix the axial piston unit so that the expected forces and torques can be transferred without any danger.

WARNING!**Risk of damage!**

Hitting or impulsive forces on the drive shaft can damage the axial piston unit.

- ▶ Do not hit the coupling or drive shaft of the axial piston unit.
- ▶ Do not place/lay the axial piston unit on the drive shaft or other sensitive attachment parts, e.g. sensors.
- ▶ Details on the permissible axial and radial forces can be found in the data sheet.

How to assemble the axial piston unit depends on the connecting elements to the drive side. The following descriptions explain the installation/mounting of the axial piston unit:

- with a coupling
- on an engine

6.4.4 Installation with coupling

How to assemble the axial piston unit with a coupling is described in detail in the following:

1. Assemble the specified coupling half onto the drive shaft of the axial piston unit according to the instructions of the coupling manufacturer.



The drive shaft of the axial piston unit is equipped with a threaded bore. Use this threaded bore to pull the coupling element onto the drive shaft. Refer to the installation drawing for the dimensions of the threaded bore.

2. Make certain that the installation location is clean and free from dirt and contaminants.
3. Clamp the coupling hub onto the drive shaft or ensure permanent lubrication of the drive shaft. This prevents the formation of frictional corrosion and the associated wear.
4. Transport the axial piston unit to the installation location.
5. Assemble the coupling onto the drive according to the instructions of the coupling manufacturer.



The axial piston unit must not be tightened down until the coupling has been correctly assembled.

6. Fix the axial piston unit at the installation location.
7. If necessary, details on the required tools and tightening torques for the fixing screws are available from the machine or system manufacturer.
 - For bell housing installation, check the coupling axial play through the bell window according to the manufacturer's instructions.
 - For flange installation, align the support for the axial piston unit with the drive.
8. When using flexible couplings, check that the drive is free of resonance after completing the installation.

6.4.5 Mounting on an engine

How to assemble the axial piston unit on an engine is described in detail in the following:

After installing on an engine, the axial piston unit is covered and is difficult to access:

- ▶ Therefore, before installing, make certain that the centering diameter centers the axial piston unit (observe tolerances) and that no impermissible axial or radial forces act on the drive shaft of the axial piston unit (installation length).
- ▶ Protect the spline of the drive shaft from frictional corrosion by providing permanent lubrication.

6.4.6 Completing assembly

1. Remove any mounted transport screws.
2. Remove the transport protection.
The axial piston unit was delivered with protective covers and plastic plugs or locking screws. These must be removed before connecting. Use appropriate tools.
3. Make certain that the sealing and functional surfaces are not damaged.



Ports which are intended for connecting lines are provided with plastic plugs or locking screws which serve as transport protection. If no connection is made, these ports must be plugged with a suitable metal locking screw since the plastic plugs are not pressure-proof.

CAUTION!



Risk of personal injury and property damage!

Operating the axial piston unit with plastic plugs can result in injuries or damage to the axial piston unit.

- ▶ Before commissioning, remove all plastic plugs and replace them with suitable, pressure-proof, metal locking screws.




Fig. 11: Removing transport protection

- | | |
|--|---|
| <ol style="list-style-type: none"> 1 Plastic transport protection for drive shaft 2 Plastic protective covers (for painted axial piston units, metal protective covers are used) | <ol style="list-style-type: none"> 3 Plastic plugs / locking screws 4 For version with power take-off, flange cover and fixing screws |
|--|---|



The adjusting screws are protected against unauthorized resetting by means of protective caps. Removal of the protective caps will void the warranty. If you need to modify the setting, please contact your responsible Rexroth Service (address as to chapter "9.5 Spare parts").

4. For versions with power take-off, assemble the auxiliary pump according to the pump manufacturer's instructions.

Assembly

6.4.7 Hydraulically connecting the axial piston unit

The machine or system manufacturer is responsible for dimensioning the lines. The axial piston unit must be connected to the rest of the hydraulic system in accordance with the hydraulic circuit diagram of the machine or system manufacturer.

CAUTION!**Damage to the axial piston unit!**

When installing hydraulic lines and hoses under mechanical stress, they are exposed to additional mechanical forces during operation which reduce the service life of the axial piston unit and the entire machine or system.

- ▶ Assemble hydraulic lines and hoses without mechanical stress.

CAUTION!**Risk of damage!**

Generally, a minimum permissible suction pressure at port "S" is specified for axial piston pumps in all installation positions. If the pressure at port "S" drops below the specified values, damage may occur which may lead to destruction of the axial piston pump.

- ▶ Make certain that the necessary suction pressure is achieved.
This is influenced by:
 - the suction cross-section and the piping
 - the pipe diameter
 - the position of the tank
 - the viscosity of the hydraulic fluid
 - the filter cartridge in the suction line
(regularly check the level of soiling of the filter cartridge)



Only connect suitable hydraulic lines to the service and function ports.

CAUTION!**Wear and malfunctions**

The cleanliness of the hydraulic fluid has a considerable impact on the cleanliness and service life of the hydraulic system. Any contamination of the hydraulic fluid leads to wear and malfunctions. In particular, contaminants, such as welding beads or metal cuttings in the hydraulic lines, may damage the axial piston unit.

- ▶ Absolute cleanliness is required.
- ▶ The axial piston unit must be installed in a clean condition.
- ▶ Make certain that all ports, hydraulic lines and add-on units (e.g. measuring devices) are clean.
- ▶ Make certain that no contaminants penetrate when sealing the ports.
- ▶ Make certain that no detergents enter the hydraulic system.
- ▶ Do not use any cotton waste or linty cloths for cleaning.
- ▶ Do not use hemp as sealant under any circumstances.

Notes on routing the lines

Observe the following notes when routing the suction and pressure lines.

- ▶ Make certain that the suction line (pipe or hose) is as short and straight as possible.
- ▶ The line cross section of the suction line is to be measured so that the minimum permissible pressure at the suction port is not dropped below and the maximum permissible pressure is not exceeded.
- ▶ Observe the air tightness of the junctions and the pressure resistance of the hose, also with respect to the external air pressure.
- ▶ With the pressure lines, make certain that the pipes, hoses and connecting elements are approved for the operating pressure range.



The ports and fixing threads are designed for the maximum pressure specified in the data sheet. The machine or system manufacturer must ensure that the connecting elements and lines correspond to the specified operating conditions (pressure, flow, hydraulic fluid, temperature) with the necessary safety factors.

Procedure

To connect the axial piston unit to the hydraulic system:

1. Remove the locking screws at the ports at which the connections are to be made according to the hydraulic circuit diagram.
2. Use only clean hydraulic lines.
3. Connect the lines according to the hydraulic circuit diagram.
Either pipes or hoses must be connected to all ports according to the installation drawing and machine or system circuit diagram or the ports plugged using suitable locking screws.



The installation drawing contains the dimensions for all connections and ports on the axial piston unit. Also observe the instructions provided by the manufacturers of the other hydraulic components when selecting the required tools.

4. Make certain that the cap nuts on the fittings and flanges are tightened correctly (observe the manufacturer's tightening torques!). Mark all checked fittings using e.g. a permanent marker pen.
5. Make certain that the pipes and hose lines and every combination of connecting piece, coupling or connecting point with hoses or pipes have been inspected by a technically qualified person for safe working condition.

Assembly

Port overview




Fig. 12: Port overview A8VO, size 107 with LA0KH2 control




Fig. 13: Port overview A8VO, size 140 with LA1S control




Fig. 14: Port overview A8VO, size 80 with EP2 control, without auxiliary pump

Table 6: Ports A8VO series 61 and 63

Designation	Port for	Standard	Danger pressure [bar] ¹⁾	State
A₁, A₂	Service line Fixing threads	SAE J518 ²⁾ DIN 13	400	O
S	Suction Fixing threads	SAE J518 ²⁾ DIN 13	1.5	O
A₃	Service line (auxiliary pump)	DIN 3852	40	O
R₁, R₃	Air bleed	DIN 3852	1.5	X ³⁾
R₂	Fluid drain	DIN 3852	1.5	X ³⁾
R₄	Flushing fluid (NG200 only)	DIN 3852	1.5	O ⁴⁾
M	Measurement for control pressure	DIN 3852	400	X
M₁, M₂ ⁵⁾	Measurement for high pressure	ISO 11926	400	X
M₃ ⁶⁾	Measurement for override control	DIN 3852	40	X
X₁	Pilot pressure for hydraulic stroke limiter	DIN 3852	40	O
X₃ ⁶⁾	Pilot pressure for override control	DIN 3852	40	O
X₄	Load pressure for load sensing	DIN 3852	400	O
Y₃	Remote control pressure	DIN 3852	40	O ⁷⁾

¹⁾ Short term pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

²⁾ Only dimensions according to SAE J518.

³⁾ Only open port "R" for filling and air bleeding.

⁴⁾ Port "R₄" Must be connected to the tank to ensure cooling and lubrication of the bearing sets.

⁵⁾ DIN 3852 applies for size 107.

⁶⁾ On the LA0 version, the port has no function and is plugged.

⁷⁾ 1x plugged, 1x open

O = Must be connected (plugged on delivery)

X = Plugged (in normal operation)

Tightening torques

The following tightening torques apply:

- Threaded hole of the axial piston unit:
The maximum permissible tightening torques $M_{G \max}$ are maximum values of the threaded holes and must not be exceeded. For values, refer to the following table.
- Fittings:
Observe the manufacturer's instruction regarding the tightening torques of the used fittings.
- Fixing screws:
For fixing screws according to DIN 13/ISO 68, we recommend checking the tightening torque in individual cases as per VDI 2230.
- Locking screws:
For the metallic locking screws supplied with the axial piston unit, the required tightening torques of locking screws M_V apply. For values, refer to the following table.

Assembly

Table 7: Tightening torques of the threaded holes and locking screws

Threaded port sizes		Maximum permissible tightening torque of the threaded holes $M_{G \max}$	Required tightening torque of the locking screws M_v	WAF hexagon socket for the locking screws
M10 x 1	DIN 3852	30 Nm	12 Nm	5 mm
M12 x 1.5	DIN 3852	50 Nm	25 Nm	6 mm
M14 x 1.5	DIN 3852	80 Nm	35 Nm	6 mm
M16 x 1.5	DIN 3852	100 Nm	50 Nm	8 mm
M18 x 1.5	DIN 3852	140 Nm	60 Nm	8 mm
M22 x 1.5	DIN 3852	210 Nm	80 Nm	10 mm
M26 x 1.5	DIN 3852	230 Nm	120 Nm	12 mm
M27 x 2	DIN 3852	330 Nm	135 Nm	12 mm
M33 x 2	DIN 3852	540 Nm	225 Nm	17 mm
M42 x 2	DIN 3852	720 Nm	360 Nm	22 mm
M48 x 2	DIN 3852	900 Nm	400 Nm	24 mm

Risk of mix-ups with threaded connections

The axial piston units are used in application areas with metric as well as with Imperial systems of units.

Both the system of units as well as the size of threaded hole and threaded plug (e.g. locking screw) must match.

Due to the limited options for visually detecting differences, there is a risk of mix-ups.

WARNING!**Risk of damage to persons and property!**

If a threaded plug which is of a different measurement system and size with respect to the threaded hole is pressurized, the threaded plug may loosen itself or even be ejected from the hole in a projectile-like manner. This can result in serious injury and damage to equipment. Hydraulic fluid can be discharged from this leakage point.

- ▶ Use the drawings (installation drawing/data sheet) to determine the required threaded plug for each fitting.
- ▶ Make certain that there are no mix-ups when assembling fittings, fixing screws and locking screws.
- ▶ For all threaded holes, use a threaded plug from the same system of units and of the correct size.

6.4.8 Electrical connection of the axial piston unit

The machine or system manufacturer is responsible for the layout of the electric control.

For electrically controlled axial piston units, the electric control must be connected according to the circuit diagram of the system manufacturer.

CAUTION!



Missing seals and connections lead to noncompliance with the protection class!

Fluids and contaminants may penetrate and damage the product.

- ▶ Prior to assembly, make certain that all seals and connectors are tight.

CAUTION!




Short circuit in event of penetrating hydraulic fluid!

Fluid can penetrate the product and cause a short circuit.

- ▶ Do not install electrically controlled axial piston units in a tank below the tank fluid level (tank installation).

Changing plug position



1. Switch off power supply to the relevant system component.
2. Electrically connect the axial piston unit (12 or 24 V).

If necessary, you can change the position of the connector by turning the solenoid.

To do this, proceed as follows:

1. Loosen the fixing nut (1) of the solenoid. To do this, turn the fixing nut (1) one turn counter-clockwise.
2. Turn the solenoid body (2) to the desired position.
3. Retighten the fixing nut. Tightening torque of the fixing nut: 5+1 Nm.

For further details and technical data, e.g. regarding the selection of a suitable mating connector, refer to data sheet RE 93010.

Tightening torque for HIRSCHMANN connector

On axial piston units with HIRSCHMANN connector, the following tightening torques apply when securing wiring sockets:

- Fixing screw M3 (1): 0.5
- Cap nut M16 x 1.5 (2): 1.5–2.5 Nm




Fig. 15: Tightening torque for HIRSCHMANN connector

7 Commissioning

WARNING!**Danger while working in the danger zone of a machine or system!**

It is not permissible to work in the danger zone of a machine or system.

- ▶ The machine or system must only be commissioned if safe working is ensured.
- ▶ Pay attention to and rectify potential danger sources before commissioning the machine or system.
- ▶ Nobody may stand in the danger zone of the machine or system.
- ▶ The emergency stop button for the machine or system must be within the operator's reach.
- ▶ Always follow the instructions of the machine or system manufacturer during commissioning.

CAUTION!**Risk of personal injury and property damage!**

Commissioning of the axial piston unit requires basic mechanical and hydraulic knowledge.

- ▶ Only qualified personnel (see chapter "2.3 Personnel qualifications") are authorized to commission the axial piston unit.

WARNING!**Risk of toxication and injury!**

Contact with hydraulic fluids may damage your health (e.g. eye injuries, skin damage, toxication upon inhalation).

- ▶ Always check the lines for wear and damage before each commissioning.
- ▶ While performing these checks, wear safety gloves, safety glasses and suitable working clothes.
- ▶ If hydraulic fluid should, nevertheless, come into contact with your eyes or penetrate your skin, consult a doctor immediately.
- ▶ When working with hydraulic fluids, strictly observe the safety instructions provided by the hydraulic fluid manufacturer.

WARNING!**Fire hazard!**

Hydraulic fluid is easily flammable.

- ▶ Keep open flames and ignition sources from the axial piston unit.

7.1 First commissioning

CAUTION!



Risk of damage to the product!

Any contamination of the hydraulic fluid leads to wear and malfunctions. In particular, contaminants, such as welding beads or metal cuttings in the hydraulic lines, may damage the axial piston unit.

- ▶ Ensure utmost cleanliness during commissioning.
- ▶ Make certain that no contaminants penetrate when sealing the gauge ports.

CAUTION!



Risk of damage to the product!

If you commission the axial piston unit without or with insufficient hydraulic fluid, the axial piston unit is damaged immediately or even destroyed.

- ▶ When commissioning or recommissioning a machine or system, make certain that the case interior and the suction and service lines of the axial piston unit are filled with hydraulic fluid and remain filled during operation.



When commissioning the axial piston unit, observe the basic safety instructions and intended use provided in chapter "2 General safety instructions".

7.1.1 Filling the axial piston unit

You will require an approved hydraulic fluid:

The machine or system manufacturer can provide you with precise details on the hydraulic fluid. Details on minimum requirements for mineral-oil based hydraulic fluids, environmentally acceptable hydraulic fluids or HF hydraulic fluids for the axial piston unit are available in the Rexroth publications RE 90220, RE 90221 and RE 90223, respectively.

To ensure the functional reliability of the axial piston unit, cleanliness level 20/18/15 according to at least ISO 4406 is necessary for the hydraulic fluid. At very high hydraulic fluid temperatures (+90 °C to maximum +115 °C), cleanliness level 19/17/14 according to at least ISO 4406 is necessary. For permissible temperatures, see the data sheet.

CAUTION!



Risk of damage to the product!

An air pocket in the area near the bearings will damage the axial piston unit.

- ▶ Make certain that the case is completely filled with hydraulic fluid during commissioning and operation.
- ▶ Check the hydraulic fluid level in the case interior regularly; if necessary, recommission.
- ▶ Make certain that the suction line is always filled with hydraulic fluid during commissioning and operation.



The axial piston unit should be filled with a filling unit (10 µm filter grade). The axial piston unit must not be operated while it is being filled.

Commissioning

CAUTION!**Danger of environmental contamination!**

The discharge or spillage of hydraulic fluid while filling the axial piston unit can lead to environmental pollution and contamination of the groundwater.

- ▶ When filling and changing the hydraulic fluid, always place a catch pan under the axial piston unit.
- ▶ Observe the information in the safety data sheet for the hydraulic fluid and the specifications provided by the system manufacturer.

1. Fill and air bleed the axial piston unit via the appropriate ports, see chapter "6.3 Installation position". The hydraulic lines of the system must also be filled.
2. Test the direction of rotation of the engine. To do this, rotate the engine briefly at the lowest rotational speed (inching). Make certain that direction of rotation of the axial piston unit matches the details on the name plate, see also chapter "4.3 Product identification", Fig. 5: Name plate. The axial piston unit is only delivered with clockwise rotation.
3. Operate the axial piston pump at a lower speed (starter speed for internal combustion engines or inching operation for electric motors) until the pump system is completely filled and bled.
4. Make certain that all ports are either connected to pipes or plugged according to the general circuit diagram.

7.1.2 Testing the hydraulic fluid supply

The axial piston unit must always have a sufficient supply of hydraulic fluid. For this reason, the supply of hydraulic fluid must be ensured at the start of the commissioning process.

When you test the hydraulic fluid supply, constantly monitor the noise development and check the hydraulic fluid level in the tank. If the axial piston unit becomes louder (cavitation), this indicates that the axial piston unit is not adequately supplied with hydraulic fluid.

Notes on troubleshooting can be found in chapter "14 Troubleshooting".

To test the hydraulic fluid supply:

1. Allow the engine to run at the slowest speed. The axial piston unit must be operated without load. Pay attention to leakage and noise.
2. Check the suction pressure at port "S" of the axial piston pump. Refer to data sheet RE 93010 for the permissible value.

7.1.3 Performing functional test**WARNING!****Risk of injury in case of incorrectly connected machine or system!**

Any change of the connections will lead to malfunctions (e.g. lift instead of lower) and thus represents a corresponding danger to persons and equipment.

- ▶ When connecting hydraulic components, observe the specified piping according to the hydraulic circuit diagram of the machine or system manufacturer.

Once you have tested the hydraulic fluid supply, you must perform a functional test on the machine or system. The functional test should be performed according to the instructions of the machine or system manufacturer.

The axial piston unit is checked for functional capability before delivery according to the technical data. During commissioning, it must be ensured that the axial piston unit was installed in accordance with the design of the machine or system.

7.1.4 Performing flushing cycle

In order to remove foreign bodies from the system, Rexroth recommends a flushing cycle for the entire system.



During the flushing cycle, the axial piston unit must be operated without load. The flushing cycle can be performed, e.g. by using an additional flushing unit. Follow the instructions of the flushing unit's manufacturer for the exact procedure during the flushing cycle.

7.2 Recommissioning after standstill

Depending on the installation conditions and ambient conditions, changes may occur in the system which make recommissioning necessary.

Among others, the following criteria may make recommissioning necessary:

- Air in the hydraulic system
 - Water in the hydraulic system
 - Old hydraulic fluid
 - Other contamination
- Before recommissioning, proceed as described in chapter "7.1 First commissioning".

7.3 Running-in phase

The bearings and sliding surfaces are subject to a running-in phase. The increased friction at the start of the running-in phase results in increased heat development which decreases with increasing operating hours. The volumetric and mechanical-hydraulic efficiency increases as well through the conclusion of the running-in phase of approx. 10 operating hours.

CAUTION!**Risk of damage by insufficient viscosity!**

The increased temperature of the hydraulic fluid during the running-in phase can cause the viscosity to drop to impermissible levels.

- ▶ Monitor the operating temperature during the running-in phase.
 - ▶ Reduce the loading (pressure, rpm) of the axial piston unit if impermissible operating temperatures and/or viscosities occur.
-

8 Operation

The product is a component which requires no settings or changes during operation. For this reason, this chapter of the instructions does not contain any information on adjustment options. Only use the product within the performance range provided in the technical data. The machine or system manufacturer is responsible for the proper project planning of the hydraulic system and its control.

9 Maintenance and repair

9.1 Cleaning and care

CAUTION!



Damage to the surface caused by solvents and aggressive detergents!

Aggressive detergents may damage the seals on the axial piston unit and cause them to age faster.

- ▶ Never use solvents or aggressive detergents.

CAUTION!



Damage to the hydraulic system and the seals!

A high-pressure cleaner's water pressure could damage the electronics and the seals of the axial piston unit.

- ▶ Do not point high-pressure cleaners at sensitive components, e.g. shaft seal ring, electrical connections and electrical components.

For cleaning and care of the axial piston unit, observe the following:

- ▶ Plug all openings with suitable protective caps/devices.
- ▶ Check whether all seals and plugs of the plug connections are securely seated to ensure that no moisture can penetrate into the axial piston unit during cleaning.
- ▶ Use only water and, if necessary, a mild detergent to clean the axial piston unit.
- ▶ Remove coarse dirt from the outside of the machine and keep sensitive and important components, such as solenoids, valves and indicators, clean.

9.2 Inspection

In order to enable long and reliable operation of the axial piston unit, Rexroth recommends testing the hydraulic system and axial piston unit on a regular basis and to document the following operating conditions:

Table 8: Inspection schedule

Task to be carried out		Interval
Hydraulic system	Check level of hydraulic fluid in the tank.	daily
	Check operating temperature (comparable load state).	weekly
	Check quality of the hydraulic fluid.	yearly or every 2000 h (which ever occurs first)
Axial piston unit	Check axial piston unit for leakage. Early detection of hydraulic fluid loss can help identify and rectify faults on the machine or system. For this reason, Rexroth recommends that the axial piston unit and system always be kept in a clean condition.	daily
	Check axial piston unit for noise development.	daily
	Check fixing elements for tight seating. All fixing elements have to be checked when the system is switched off, depressurized and cooled down.	monthly

9.3 Maintenance

The axial piston unit is low maintenance when used as intended.

The service life of the axial piston unit is heavily dependent on the quality of the hydraulic fluid. For this reason, we recommend changing the hydraulic fluid at least once per year or every 2000 operating hours (whichever occurs first) or having it analyzed by the hydraulic fluid manufacturer or a laboratory to determine its suitability for further use.

The service life of the axial piston unit is limited by the service life of the built-in bearings. The service life can be requested from the responsible Rexroth Service partner, see "9.5 Spare parts" for address. Based on these details, a maintenance period is to be determined by the system manufacturer for the replacement of the bearings and included in the maintenance schedule of the hydraulic system.

9.4 Repair

Rexroth offers a comprehensive range of services for the repair of Rexroth axial piston units.

Repairs of the axial piston unit may only be performed by authorized, skilled and instructed personnel.

- ▶ Only use genuine spare parts from Rexroth for repairing the Rexroth axial piston units.

Tested and pre-assembled original Rexroth assembly groups allow for successful repair requiring only little time.

9.5 Spare parts

CAUTION!**Personal injury and property damage due to faulty spare parts!**

Spare parts that do not meet the technical requirements specified by Rexroth may cause personal injury or property damage.

- ▶ Use only original spare parts from Rexroth.

The spare parts lists for axial piston units are order specific. When ordering spare parts, quote the material and serial number of the axial piston unit as well as the material numbers of the spare parts.

Please address all questions regarding spare parts to your responsible Rexroth Service partner or the service department of the manufacture's plant for the axial piston unit.

Bosch Rexroth AG
Glockeraustraße 2
89275 Elchingen, Germany
Phone +49 (0) 73 08 82-0
Fax +49 (0) 73 08 72 74
service.elchingen@boschrexroth.de

For the addresses of foreign subsidiaries, please refer to
www.boschrexroth.com/addresses

10 Decommissioning

The axial piston unit is a component that does not require decommissioning. For this reason, this chapter of the instructions does not contain any information. For details about how to disassemble or replace your axial piston unit, please refer to chapter "11 Disassembly and replacement".

11 Disassembly and replacement

11.1 Required tools

Disassembly can be performed with standard tools. No special tools are necessary.

11.2 Preparing for disassembly

WARNING!**Risk of injuries due to disassembling under pressure and voltage!**

If you do not switch off the pressure and power supply before disassembling the product, you may get injured or the device or system components may be damaged.

- ▶ Make certain that the relevant system components are not under pressure or voltage.

-
1. Decommission the entire system as described in the overall manual for the machine or system.
 2. Relieve the hydraulic system according to the instructions of the machine or system manufacturer.

11.3 Disassembling the axial piston unit

Proceed as follows to disassemble the axial piston unit:

1. Make certain that the hydraulic system is depressurized.
2. Check whether the axial piston unit has cooled down far enough so that it can be disassembled without danger.
3. Place a catch pan under the axial piston unit to collect any hydraulic fluid that may escape.

CAUTION!**Danger of environmental contamination!**

The discharge or spillage of hydraulic fluid while disassembling the axial piston unit can lead to environmental pollution and contamination of the groundwater.

- ▶ When draining the hydraulic fluid, always place a catch pan under the axial piston unit.
 - ▶ Observe the information in the safety data sheet for the hydraulic fluid and the specifications provided by the system manufacturer.
-

4. Loosen the lines and collect the escaping hydraulic fluid in the collector.
5. Remove the axial piston unit. Use an appropriate lifting device.
6. Completely empty the axial piston unit.
7. Plug all openings.

11.4 Preparing the components for storage or further use

- ▶ Proceed as described in section "5.2 Storing the axial piston unit".

12 Disposal

Observe the following points when disposing of the axial piston unit:

1. Completely empty the axial piston unit.
2. Dispose of the hydraulic fluid according to the national regulations of your country.
3. Disassemble the axial piston unit into its individual parts and properly recycle these parts.
4. Separate parts by:
 - Cast parts
 - Steel
 - Nonferrous metal
 - Electronic waste
 - Plastic
 - Seals.

12.1 Environmental protection

Careless disposal of the axial piston unit, the hydraulic fluid and the packaging material could lead to pollution of the environment.

- ▶ Therefore, dispose of the axial piston unit, the hydraulic fluid and the packaging material in accordance with the currently applicable regulations in your country.
- ▶ Dispose of hydraulic fluid residues according to the applicable safety data sheets for these hydraulic fluids.

13 Extension and conversion

Do not convert the axial piston unit. This also includes a modification of the adjusting screws.



The warranty from Rexroth only applies to the delivered configuration. In case of extensions or conversions, the warranty will become void.



Adjusting screws are protected against unauthorized resetting by means of protective caps. Removal of the protective caps will void the warranty. If you need to modify the setting, please contact your responsible Rexroth Service (address as to chapter "9.5 Spare parts").

14 Troubleshooting

The following table may assist you in troubleshooting. The table makes no claim for completeness.

In practical use, problems which are not listed here may also occur.

14.1 How to proceed for troubleshooting

- ▶ Always act systematically and targeted, even under pressure of time. Random and imprudent disassembly and readjustment of settings could result in the inability to ascertain the original error cause.
- ▶ First obtain a general overview of how your product works in conjunction with the entire system.
- ▶ Try to determine whether the product worked properly in conjunction with the entire system before the error occurred.
- ▶ Try to determine any changes of the entire system in which the product is integrated.
 - Were there any changes to the product's operating conditions or operating range?
 - Were there any changes (conversions) or repairs on the complete system (machine / system, electrics, control) or on the product? If yes, which?
 - Was the product or machine operated as intended?
 - How did the malfunction appear?
- ▶ Try to get a clear idea of the error cause. Directly ask the (machine) operator.
- ▶ If you cannot rectify the error, contact one of the contact addresses which can be found under: www.boschrexroth.com/addresses.

Troubleshooting

14.2 Malfunction table

Table 9: Malfunction table for variable pumps

Fault	Possible cause	Remedy
Unusual noises	Drive speed too high.	Machine or system manufacturer.
	Wrong direction of rotation.	Ensure correct direction of rotation.
	Insufficient suction conditions, e.g. air in the suction line, insufficient diameter of the suction line, viscosity of the hydraulic fluid too high, suction height too high, suction pressure too low, contaminants in the suction line.	Machine or system manufacturer (e.g. optimize inlet conditions, use suitable hydraulic fluid).
		Completely air bleed axial piston unit, fill suction line with hydraulic fluid.
		Remove contaminants from the suction line.
	Improper fixing of the axial piston unit.	Check fixing of the axial piston unit according to the specifications of the machine or system manufacturer. Observe tightening torques.
	Improper fixing of the attachment parts, e.g. coupling and hydraulic lines.	Fix attachment parts according to the information provided by the coupling or fitting manufacturer.
	Pressure-relief valve of the axial piston unit (pressure cut-off).	Air bleed axial piston unit Check viscosity of the hydraulic fluid Contact Rexroth Service.
Mechanical damage to the axial piston unit.	Exchange axial piston unit, contact Rexroth Service.	
No or insufficient flow	Faulty mechanical drive (e.g. defective coupling).	Machine or system manufacturer.
	Drive speed too low.	Machine or system manufacturer.
	Insufficient suction conditions, e.g. air in the suction line, insufficient diameter of the suction line, viscosity of the hydraulic fluid too high, suction height too high, suction pressure too low, contaminants in the suction line.	Machine or system manufacturer (e.g. optimize inlet conditions, use suitable hydraulic fluid).
		Completely air bleed axial piston unit, fill suction line with hydraulic fluid.
		Remove contaminants from the suction line.
	Hydraulic fluid not in optimum viscosity range.	Use suitable hydraulic fluid (machine or system manufacturer).
	External control of the control device defective.	Check external control (machine or system manufacturer).
	Insufficient pilot pressure or control pressure.	Check pilot pressure or control pressure, contact Rexroth Service.
	Malfunction of the control device or controller of the axial piston unit.	Contact Rexroth Service.
Wear of axial piston unit.	Exchange axial piston unit, contact Rexroth Service.	
Mechanical damage to the axial piston unit.	Exchange axial piston unit, contact Rexroth Service.	

Table 9: Malfunction table for variable pumps

Fault	Possible cause	Remedy
No or insufficient pressure	Faulty mechanical drive (e.g. defective coupling).	Machine or system manufacturer.
	Drive power too low.	Machine or system manufacturer.
	Insufficient suction conditions, e.g. air in the suction line, insufficient diameter of the suction line, viscosity of the hydraulic fluid too high, suction height too high, suction pressure too low, contaminants in the suction line.	Machine or system manufacturer (e.g. optimize inlet conditions, use suitable hydraulic fluid).
		Completely air bleed axial piston unit, fill suction line with hydraulic fluid.
		Remove contaminants from the suction line.
	Hydraulic fluid not in optimum viscosity range.	Use suitable hydraulic fluid (machine or system manufacturer).
	External control of the control device defective.	Check external control (machine or system manufacturer).
	Insufficient pilot pressure or control pressure.	Check pilot pressure or control pressure, contact Rexroth Service.
	Malfunction of the control device or controller of the axial piston unit.	Contact Rexroth Service.
	Wear of axial piston unit.	Exchange axial piston unit, contact Rexroth Service.
Mechanical damage to the axial piston unit.	Exchange axial piston unit, contact Rexroth Service.	
Output unit defective (e.g. hydraulic motor or cylinder).	Machine or system manufacturer.	
Pressure/flow fluctuations	Axial piston unit not or insufficiently air bled.	Completely air bleed axial piston unit.
	Insufficient suction conditions, e.g. air in the suction line, insufficient diameter of the suction line, viscosity of the hydraulic fluid too high, suction height too high, suction pressure too low, contaminants in the suction line.	Machine or system manufacturer (e.g. optimize inlet conditions, use suitable hydraulic fluid).
		Completely air bleed axial piston unit, fill suction line with hydraulic fluid.
	Remove contaminants from the suction line.	
Hydraulic fluid temperature too high	Excessive inlet temperature at the axial piston unit.	Machine or system manufacturer: inspect system, e.g. malfunction of the cooler, insufficient hydraulic fluid in the tank.
	Malfunction of the pressure control valves (e.g. pressure cut-off, pressure controller).	Contact Rexroth Service.
	Wear of axial piston unit.	Exchange axial piston unit, contact Rexroth Service.

15 Technical data

The technical data of your axial piston unit can be found in data sheet RE 93010.

The data sheets can be found on the internet under www.boschrexroth.com/axial-piston-pumps

The preset technical data of your axial piston unit can be found in the order confirmation.

16 Appendix

16.1 Address directory

For the addresses of foreign subsidiaries, please refer to www.boschrexroth.com/addresses

17 Index

A

Abbreviations 5
Address directory 48
Assembly 11, 21, 24
 Completing 27
 General instructions 25
 on an engine 26
 Preparation 24
 With coupling 26

B

Below-tank installation 23

C

Care 40
Caution 7
Changing solenoid position 33
Cleaning 40
Commissioning 34
 first 35
Connecting
 Electrical 33
 Hydraulic 28
Conversion 44
Corrosion protection 19
Cylinder 11

D

Danger 7
Decommissioning 42
Delivery contents 10
Device description 11
Dimensions 17, 25
Direction of rotation 24
Disassembly 42
 Performing 42
 Preparing 42
Disposal 44
Documentation 4
Drive shaft 11
Drive-shaft flange 11

E

Environmental protection 44

F

Filling 35
Flushing cycle 37
Forklift truck 17
Functional description
 Control 12
 Open circuit 11
 Pump 12
Functional test 36

G

General instructions 25

H

Hydraulic fluid 35

I

Identification 16
Inspection 40
Installation
 With coupling 26
Installation conditions 21
Installation position 23
 Below-tank installation 23

L

Lens plate 11
Lifting device 17
Lifting strap 18

M

Maintenance 40, 41
Malfunction table 46
Mounting
 on an engine 26

N

Name plate 16
Notes
 General 7, 25

O

Obligations
 of the operator 9
Operation 39

P

Performance description 11
Piston 11
Port overview 30
Port plate 11
Product description 11

Q

Qualifications
 Personnel 6

R

Recommissioning
 After standstill 37
Repair 41
Replacement 42
Ring screw 17
Running-in phase 38

S

Safety instructions 6, 7
Service line port 11
Spare parts 41
Storage 17
Storage time 19
Storing 19
Stroke piston 11
Suction port 11

T

Technical data 48
Tightening torques 31
Tools 42
Transport 17
 With lifting device 18
 With ring screw 17
Transporting 17
Troubleshooting 45

U

Unpacking 21
Use
 Improper 6
 Intended 6

W

Warning 7
Warranty 8, 19, 27, 35, 44
Weights 17

Bosch Rexroth AG
Hydraulics
Axial Piston Units
Glockeraustraße 2
89275 Elchingen, Germany
Phone +49 (0) 73 08 - 82 0
Fax +49 (0) 73 08 - 72 74
info.brm-ak@boschrexroth.de
www.boschrexroth.com/axial-piston-pumps